


BT/L Series Intelligent Flow Peristaltic Pump Operation Manual

CE



Safety Precautions



Important information:

Be sure to read the manual carefully before operation!

	This icon warns: Keep fingers away from moving parts.
	This icon warns: Be careful.
	This icon warns: Be careful, the surface is hot.
	This icon warns: Be careful, electric shock hazard.
	This icon warns: To recycle this product.
	This icon warns: Personal protective equipment (PPE) must be worn.

Danger:

	Please use the same power supply as that on the nameplate of the machine, otherwise the equipment will be damaged!
	Do not disassemble the shell or modify the interior of the equipment by yourself, otherwise it may cause malfunctions or even electric shock accidents!
	When installing and disassembling the pump tube, please turn off the power first and do not approach the rotating roller to prevent fingers and clothing from getting entangled in the mechanical mechanism!
	When installing and disassembling external control devices, please turn off the power first to prevent electric shock accidents or damage to the equipment!

	The grounding plug must be well grounded at all times, otherwise there is a risk of electric shock, electromagnetic interference, or induced static electricity!
	If it is used to transport dangerous liquids, special operating procedures must be developed for this liquid, and personnel must also be prevented from being injured during using.
	This product is not suitable for explosion-proof environment, and it should not be used in explosive environment.

Warning:

	Before using, please confirm that the transmitted liquid will not react chemically with the tube or pump head, otherwise it will damage the tube or pump head. If unsure, please consult our engineers.
	The tube is a vulnerable part, please check it regularly. Our company is not responsible for the loss caused by tube damage, especially the leakage of toxic, harmful and valuable liquids!
	Due to the fact that the actual working environment conditions (including temperature, humidity, acid, alkali, organic solvent and other corrosive environment, dust environment, power supply voltage, etc.) exceed our technical specifications and the machine is damaged, our company is responsible for the paid warranty, which is not within the scope of normal warranty.
	The primary protection for the operator against injury from the moving parts of the pump is provided by the pump head safety device. Please note that safety devices vary from product to product, depending on the model of pump head. See pump head section in manual.
	If the pump was running before the power failure, the pump will automatically start when the power is turned back on.

Contents

Peristaltic Pump Introduction	1	Ordering Information	44
Description	1	Optional Accessories Table	44
Applications	1	Naming Rules	45
Functions and Features	2	Technical Parameters	46
Components and Interfaces	3	Flow Rate Chart of the Pump	49
Display Panel and Operating Keypad	4	Suitable Pump Heads for Peristaltic Pump Drives	50
Keypad	4	External Control Input and Output Performance	51
Icon Description	5		
Touch Screen	6		
Status Bar	6		
Operating Zone	9		
Navigation Keys	10		
External Control Interface	24		
Installation Instructions	25		
Before Operation	25		
Install Pump Head and Tube	26		
Power Connection	26		
Operation Instructions	27		
First Run Wizard	27		
Flow Calibration	28		
Working Mode	31		
External Control Mode	33		
Communication Mode	36		
Foot Switch Mode	38		
Malfunction and Maintenance	40		
Daily Maintenance	41		
Maintenance Worksheet	42		
Malfunction Solutions	43		
Dimensions	44		

Peristaltic Pump Introduction

Peristaltic pump is a safe and reliable fluid transmission equipment, the fluid only contacts with the inner wall of the tube line, through squeeze the tube to realize the fluid transmission.

Its unique no-valve, no-seal, tube line-integrated transmission design, Ensure the cleanliness of the fluid, reduce the risk of leakage, and make the fluid more reliable, safe and clean way of transmission.

Working Principle

The tube fits between the roller and the pressure block, forming a seal at the point of contact when squeezed. As the roller rotates and advances along the tube, the sealing contact advances with it. As the rollers pass, the tube returns to its original shape, creating a vacuum that draws in liquid. Before the roller reaches the end of the pressure block, a second roller starts compressing the tube at the beginning of the pressure block, isolating the fluid between the two compression points. As the first roller clears the pressure block, the second roller continues to expel the liquid through the discharge port of the tube. At the same time, a new partial vacuum is created behind the second roller, sucking in more liquid from the inlet. There is no backflow and siphoning, and the pump effectively seals the tube when not in use, so there is no need for a separate valve.

Description

BT100L/BT300L/BT600L intelligent flow peristaltic pumps are mainly used for precise metering and quantitative dispensing of liquids to achieve high-precision flow transmission control. Compared with the previous generation of products, it adopts a larger size true-color LCD touch screen, which is more convenient to operate and more comprehensive to display information. It support RS485 communication. Adding more settings on the basis of MODBUS can adapt to the requirements of different communication equipment.

This series of intelligent flow peristaltic pumps include

BT100L flow range: 0.00011-750mL/min, rotate speed 0.1-150rpm.

BT300L flow range: 0.005-1750mL/min, rotate speed 0.1-350rpm.

BT600L flow range: 0.005-3000mL/min, rotate speed 0.1-600rpm.

Applications

- The pump body does not touch the liquid.
- No valve blockage.
- The inner surface is smooth and easy to clean.

- The suction lift can reach up to 8 meters of water column.
- Low shear force, can be used to transfer emulsions or liquids containing foam, cells, etc.
- Suitable for transporting liquids containing gases, magnetic beads, or suspensions containing small particles.
- It is suitable for precise transmission and quantitative dosing, and can achieve a certain accuracy by choosing appropriate tube diameter and filling efficiency.
- Suitable for transferring liquids with a certain degree of viscosity;
- The liquid only comes into contact with the tube
- If use food and medical grade tube, this pump can be used for food and medical transmission and filling.
- Replacement tube of special material to transfer abrasive liquids.

Functions and Features

- Color LCD display, touch screen plus key operation.
- With forward and reverse rotating, start and stop, speed regulation and full speed functions.
- The speed resolution is 0.1rpm, and the speed accuracy error is less than $\pm 0.2\%$.
- It has the functions of flow display, flow control, liquid volume accumulation and flow calibration.
- Flow mode and time dispensing mode.
- Five groups of parameters can be pre-stored in time dispensing mode.
- The expert system minimizes the user's difficulty in using it.
- Intelligent temperature control function to minimize the noise of peristaltic pump.
- Motor loss speed alarm function.
- Software settings switch external analog speed regulation mode (0-5V/0-10V /4-20mA), External control signal 5-24V wide range input, control start and stop, forward and reverse rotating, external control signal optoelectronic isolation.
- RS485 communication, support MODBUS protocol, a variety of communication parameters can be set, easy to connect with various control equipment.

- The circuit board is sprayed with conformal coating to achieve the effect of dustproof and moistureproof.
- Super anti-interference characteristics, wide voltage design, suitable for complex power supply environment.
- The stainless steel shell is easy to clean and effectively protects against the corrosion of various acids, alkalis, salts and organic solvents

Components and Interfaces




Figure 1 Components and Interfaces

Display Panel and Operating Keypad




Figure 2 Display Panel

◆ Keypad

 **Start /Stop Key:** Control the start and stop of the pump.

 **Direction Keys:** Control the direction of pump operation, switch between forward (clockwise) and reverse (counterclockwise).

 **Full Speed Key:** The pump runs at maximum speed and is used for filling or emptying liquid.

 **MODE Key :**

1. Choose Working Mode: In the main interface, when the machine is in the stop state, it will enter the interface for choosing the working mode. when it is in an interface other than the main interface, press the key to return to the previous interface.

◆Icon Description

Icon	Function	Icon	Function
	Tone on/off		Locked/Unlocked
	Internal control mode		Foot switch mode
	Current mode		Voltage mode
	Communication connection		Communication Disconnected
	Direction of rotation		Start/Stop
	Mode setting		Decrease key Increase key
	Quick setup		Preview mode
	System menu		Calibration wizard
	Back to previous step/previous page		Exit mode
	Enter		Go to the next step/next page

Table 1 Description of Display Icons

◆ Touch Screen




Figure 3 Touch Screen

◆ Status Bar

A. Tone State: Display the current prompt tone and key tone on or




Figure 4 Tone State Icon

B. Locked. Displays the current locked state. When the device is locked, the control mode and system parameters cannot be modified.




Figure 5 Locked and Unlocked Icons

C. Control Mode. Display the current control mode, there are four modes, as shown in Figure 6:

- **Internal Control Mode:** The operation of the pump is controlled by keys and touch screen.
- **Foot Switch Mode:** The start and stop of the pump is controlled by the foot switch, and other parameters are controlled by keys and touch screen.
- **Current Mode:** The flow of the pump is controlled by an external analog 4-20mA, the start and stop and direction are controlled by an external signal, and the key does not work.
- **Voltage Mode:** The flow of the pump is controlled by an external analog 0-5V or 0-10V, the start/stop and direction are controlled by an external signal, and the key does not work.




Figure 6 Control Mode

D. Communication State: Display whether the current communication is connected, as shown in the figure below:




Figure 7 Communication State Icon

E. Direction of Rotation: Displays the current direction the pump is running. The icon is displayed in the stop state as shown below:




Figure 8 When the Pump Stops Running Counterclockwise

In the running state, the orange ring displays the current running direction in animation, as shown in the figure below:



Figure 9 When the Pump is Running Clockwise

F. Running State: The icon indicates the current running state.

G. Temperature Display: Display the current internal temperature of the drive, as shown in Figure 9 above, the current temperature of the drive is 34°C.

◆ Operating Zone

A. Numerical Input Setting: In the stop state, you can click the numerical value, and directly input the numerical value to be modified in the pop-up dialog box, pay attention to the numerical range and unit on the dialog.




Figure 11 Value Input Box



Note: If the flow rate needs to be displayed accurately, flow must be calibrated! See page 28 for details.

B. Unit Setting: In the stop state, click the unit key to pop up a dialog box, choose the unit to be the figure below is to set the flow unit:





Figure 12 Unit Choose Box

◆ Navigation Keys


Mode Setting: Set the specific control parameters in different working modes. Turn on/off the prompt sound. Locked/Unlocked



Flow-Internal Control Mode



Flow-External Control Mode



Time Dispensing Mode

Figure 13 Mode Setting Interface



Preview Mode: Check the running state and parameter changes. The current operating parameters are displayed on the left side of the interface, and the operating state is displayed on the right side.



Figure 14 Preview Interface

In the flow mode, orange means stop state, green means running state, and yellow means pause state As shown below:



Figure 15 Running State Indication

In the running state, the rotating direction of the ring indicates the running direction of the pump, as shown in the figure below, if it changes sequentially from left to right, it means clockwise running. If it changes from right to left, it is running counterclockwise.




Figure 16 Running Direction Indication

In the dispensing mode, orange means stop state, green means running state, and yellow means pause state.



Figure 17 Dispensing State Indication



Quick Setting: Can reset the accumulated liquid volume and accumulated times, turn on/off the prompt sound, lock/unlock.




Figure 18 Quick Setting Interface

Fine-tuning Key: In the preview interface of the flow mode, adjust the flow in real time. Click the increase icon to increase the flow by one minimum unit. Click the decrease icon to decrease the flow by one minimum unit. Press and hold the increase icon or decrease icon for 1 second, and continue to press the key, and the flow rate will increase or decrease rapidly. As shown below:




Figure 19 Fine-tuning Key



Calibration Wizard: In order to improve the flow accuracy of the liquid transmission, it is necessary to calibrate the flow. According to the prompt of the wizard, use the balance or graduated cylinder to weigh the transmission liquid, so that the displayed value corresponds to the actual flow rate accurately.



Note: If the flow rate needs to be displayed accurately, flow must be calibrated! See page 28 for details.



System Menu: In the stop state, press the system menu icon to enter the main control interface, the interface is as follows:




Figure 20 System Menu Interface

Common Parameter: Set the common parameters of the peristaltic pump, and view the menu by sliding up and down on the touch screen, as shown in the figure below:




Figure 21 General Parameter Interface

Pump Head Setting: According to the actual condition, choose the suitable pump head model, and view other options by sliding up and down on the touch screen.



Figure 22 Pump Head Setting Interface



Note: When DG and DT10 pump heads are chosen, the system defaults to limit the maximum speed to 100 rpm.

- **Tube Setting:** According to the actual condition, choose the suitable tube model, and swipe up and down on the touch screen to view other options.




Figure 23 Tube Setting Interface



Note: Each pump head corresponds to a series of suitable tubes, please choose the suitable pump head and tube!

- **Anti-drip Setting:** When the peristaltic pump stops, in order to prevent the liquid in the tube line from dripping, the motor of the peristaltic pump rotates in the opposite direction for an angle to suck back the liquid in the tube line. Click the anti-drip setting key to adjust the reverse angle. When the angle is set to 0, this function is off.



Figure 24 Anti-drip Setting Interface

- **Reverse Speed:** According to the actual condition, set the speed of pump back-suction.



Figure 25 Reverse Speed Interface

- **Communication Setting:** Set the parameters of RS485 communication, as shown in the figure below:




Figure 26 Communication Setting Interface

- **Advanced Settings:** After entering the correct user password (default is blank) in the password input interface, enter the common parameters again to view more parameter settings, and view the menu by sliding up and down on the touch screen.




Figure 27 Advanced Setting Interface

BT/ L Series Peristaltic Pump Operation Manual

- **External Control Direction:** Choose the external control rotation direction signal is level mode or pulse mode. The level mode means that the external control signal controls the running direction of the pump by maintaining the high and low level signals. The pulse mode means that the external control signal controls the operation of the pump by detecting the rising edge/falling edge generated when switching between high and low levels Direction, e.g. controlled by a unlock key (effective in external control mode).




Figure 28 External Control Mode Interface

- **Deceleration Time:** Refers to the time from when the pump receives the stop signal to when the pump stops rotating. The problem of splashing during liquid filling can be reduced by modifying this parameter.




Figure 29 Deceleration Time Interface

- **Pulse Signal:** When the external control signal is a pulse signal, the falling edge or rising edge is valid through options. The falling edge refers to the transition from high level to low level, and the rising edge





Figure 30 Pulse Signal Interface

- **Level Signal:** When the external control signal is a level signal, you can choose whether it is active at low level or high level through the option.



Figure 31 Level Signal Interface

- **Calibration Wizard:** In order to improve the flow accuracy of the liquid transmission, it is necessary to calibrate the flow. According to the prompt of the wizard, use the balance or graduated cylinder to weigh the transmission liquid, so that the displayed value corresponds to the actual flow rate accurately.



BT/ L Series Peristaltic Pump Operation Manual

■ **System Parameters:** Set the system parameters of the peristaltic pump, and view the menu by sliding up and down on the touch screen, as follows:




Figure 32 System Parameter Interface

• **Date Setting:** Set the current year, month, and day, choose the year and month with the left and right keys, then touch the screen to manually choose the date, and finally press the exit key to automatically save the date just set.



Figure 33 Date Setting Interface

• **Time Setting:** Set the current hour, minute and second, set it by pressing the up and down keys, and finally press the exit key to automatically save the time just set.




Figure 34 Time Setting Interface

• **Language Setting:** Choose the language used, Chinese or English.



Figure 35 Language Setting Interface

- **Backlight Setting:** Set the brightness of the LCD screen (1%-100%).
- **Motor Loss Speed Alarm:** When a stalled rotor occurs during the operation of the device, the drive will automatically stop running, and it is turned off by default.
- **Restore Default Value:** Restore all parameters to factory default value, need to restart the drive to take effect. You can also press and hold the direction key (with a circular arrow icon) and the mode key (with a 'MODE' icon) at the same time after turning off the power to turn on the power, and the main interface will be displayed normally after the power is turned on, and the device will be restored to the factory settings.



Figure 36 Restore Default Value Interface

- **Tube Replacement Reminder:** After opening, when the theoretical remaining life of the tube is 0, the Enterprise Cloud Pump APP will send a notification on the mobile phone to remind the user that the tube may be damaged and needs to be replaced in time. it is turned off by default.



Figure 37 Tube Replacement Reminder Interface

- **Reset Tube Life:** Set the tube life to the initial value, usually after replacing the tube.




Figure 38 Reset Tube Life Interface

- **Reset WIFI:** After reset, the WIFI binding information will be cleared, and the drive will enter the state of waiting for network distribution. At this time, it can be re-bound (in the main interface of any working mode, press and hold the " MODE " key for 10 seconds to reset).




Figure 39 Reset WIFI Interface

- **Information Query:** For the usage information of the peristaltic pump, view it by sliding up and down on the touch screen.




Figure 40 Information Query Interface

- **Operating Instructions:** Enterprise company's contact information and brief introduction.

- **Password Setting:** Set the user password, which is used to add/unlock the device, prevent others from modifying parameters, and view more common parameters.

The default password is empty.

In the main control interface, click the mode setting key , click lock, the lock key turns blue to indicate that the device is locked, click the lock again, and the

BT/ L Series Peristaltic Pump Operation Manual

password setting window will pop up, enter the set password, click OK and it will automatically jump to in the main control interface, click the mode setting key  again, and you will find that the lock key is gray, which means it is unlocked. If the password is incorrectly, it will still automatically jump to the main control interface. It is necessary to judge whether the device is locked or unlocked by observing the state of the unlock key.

Change Password

The screen is shown in the left picture below when setting a password for the first time. There is no password change key, you need to click OK first, and then it will automatically jump back to the main interface. Enter the password setting interface again, and you will find the change password key in the screen. As shown in the right picture below. Then, enter the password you want to set, and click Change Password key to complete the initial password setting.

The number of digits of the password setting is 1-8 digits, and the specific digits can be freely chosen.





Figure 41 Password Setting Interface

If you forget the password, you need to contact Enterprise to reset or retrieve it.


■ **Return to Main Control:** Return to the main control interface.

External Control Interface



DB15 Pin	English Notes	Description
1	ADC_W	The positive input of the external analog signal
2	B	Communication interface, B pole of RS485
3	A	Communication interface, A pole of RS485
4	VCC_W	External DC power input
5	DAC	Analog voltage signal output
6	CW_W	External input signal to control direction
7	PWM	Pulse signal output
8	COM	External commons
9	AGND	Negative input of external analog signal
10	+12V	Positive of internal +12V power source
11	GND	Ground of Internal power source
12	CW	Internal output to control direction
13	RS_W	External input to control start/stop
14	PWM_W	External pulse signal input
15	RS	Internal output to control start/stop

Table 2 Definition of External Control Pins



DB9 Pin	English Notes	Description
1		
2	RXD	Receive data
3	TXD	Send data
4		
5	GND	Signal ground line
6		
7		
8		
9		

Table 3 Definition of RS232 Pins

	Note: Do not connect power to the external control connector. Please provide the correct signals according to the legend pins. Do not exceed the range specified by the signal value. Do not connect the supply voltage across other pins. Otherwise it may cause permanent damage and will not be covered by the warranty.
	Note: Low voltage signals must be isolated from mains power. Use a separate shielded ground input wire.
	Note: Use a qualified protective wire sleeve at the end of the multi-strand cable, otherwise there will be a risk of damage to the equipment.

Installation Instructions

◆ Before Operation

- Please compare the packing list to check whether all accessories are wrong or damaged when you open the outer package of the pump. Please contact Enterprise or agent in time, if you find any problems.

- Read the operation manual carefully, and keep it at hand, or keep it in a fixed place for reference at any time.
- Place the pump on a level table with the rear at least 20 cm away from obstacles.

◆ Install Pump Head and Tube

For detailed installation steps, please refer to the operation manual of the corresponding pump head!

Install YZ15, YZ25 pump head

- Align the flat shaft of the pump head with the groove of the drive coupling and push in. Then turn the pump head so that the screw holes of the pump head are aligned with the screw holes of the pump head bracket of the drive and push in. After fitting the pump head and its bracket, put two fixing screws into the fixing holes of the pump head and tighten them.
- Pull the pump head lever to open the pump head, put the tube into the pump head smoothly and straighten it, pull the lever in the opposite direction to the horizontal position, and the tube is installed.

Install DG multichannel pump head

- Align the flat shaft of the pump head with the groove of the drive coupling and push it in, turn the pump head so that the positioning hole at the rear of the pump head is aligned with the positioning pin of the pump head bracket of the drive and push in, fit the pump head to the pump head bracket, and then insert the two hexagon socket screws into the fixing holes on the inside of the pump head and tighten them.
- Put the tube into the card smoothly and straighten it, push the tube clamps at both ends of the tube into the fixing groove, firstly clamp the left end of the card into the cylindrical guide rail of the pump head, and then clamp the other end of the card into the square guide rail.

◆ Power Connection

Plug the supplied power cord into the power socket on the rear of the drive.

	Note: Make sure all power supply wires are rated for equipment wattage.
	Note: The pump must be located so that it can be easily disconnected from the power source when the equipment is in use.



Note: Please use the same power supply as that on the nameplate of the machine, otherwise the equipment will be damaged!

Operation Instructions

◆ First Run Wizard

The pump has preset default operating parameters, as shown in the table below:

Parameter	Default Setting
Language Setting	Chinese
Screen Brightness (backlight value)	50%
Password	Blank
Key Tone	Tone on
Default Working Mode	Internal Control-Flow Mode
Default Volume Configuration	60μl/min
Default Speed	1.0 rpm
Direction of Rotation	Clockwise Rotation
Delayed Start	Closed
Pump Head Setting	YZ15
Tube Setting	13#
Anti-drip Setting	Angel O(close)
Reverse speed	600RPM
Communication rate	9600
Parity	Even
Byte Order	CDAB
Pump Number Setting	1
Direction of External Control	Pulse Signal
External control signal to control start/stop (foot switch mode)	Pulse Signal
External control signal to control start/stop (other external control modes)	Level Signal
Deceleration Time	0.5 Seconds
Pulse Signal	Falling Edge
Level Signal	Low Level

Table 4 List of Device Default Parameters

◆ Flow Calibration

Weigh the actual transported liquid with a balance or graduated cylinder to calibrate the flow of pump. Calibration must be performed in the following cases.

- First run
- Replace pump head
- Replace tube
- Dual pump heads deliver the same liquid
- Reinstall the tube
- Continuous working time is longer

The specific operation is as follows:

- 1) Install the pump head and tube, and prepare a suitable balance or measuring cylinder and measuring cup.
- 2) In the common parameters, "pump head" and "tube Setting" are set to the actual pump head and tube (refer to Figure 22 and Figure 23 in the introduction of common parameters for details).
- 3) Press the full speed key to fill the tube with fluid.
- 4) In the stop state, click the calibration wizard icon or click the system menu parameter setting icon to enter the system parameter setting interface, and click the calibration wizard icon.
- 5) Enter the calibration wizard interface, the system displays the current flow and liquid volume to be calibrated, where the flow rate refers to the speed of the transmission liquid, and the liquid volume refers to the volume of the transmission liquid.

As shown in the figure below, 9.000mL/min is the flow rate to be tested, and 6.000ml is the liquid volume to be tested. These two values and units can be directly clicked to modify, and then click key to enter the test interface. And click key to exit the calibration wizard and return to the system parameter interface.




Figure 42 Calibration Wizard Setting Interface

BT/ L Series Peristaltic Pump Operation Manual

6) The test interface is as follows:






Figure 43 Calibration Wizard Actual Measurement Interface



Prepare the measuring cylinder or beaker, make sure the tube is full of liquid, press start/stop key, the peristaltic pump starts to transfer the liquid, observe the progress bar at the bottom, wait for the peristaltic pump to stop automatically after the transfer is completed, weigh the liquid with a balance or a measuring cylinder, and record measured value. The above process can be repeated to weigh the liquids that have been transferred multiple times, and fill in the values in Test 1, Test 2, and Test 3, pay attention to choose the correct unit, and then click **▷** to enter the calibration calculation interface.

If you want to re-modify the test flow and liquid volume, you can click **↶** to re-enter the value. Click **◀** key to exit the calibration wizard and return to the system parameter interface.



The test value can choose to input one or more sets of data, and the system will automatically calculate the average value.

7) The system automatically calculates the correction coefficient and displays the reference of the original coefficient. If the deviation is more than double, please pay attention to whether the following aspects are wrong.

- There is an error in the measurement
- The unit of the test value is wrong
- The pump head or tube model is set incorrectly.
- Liquid viscosity is too high
- Use double pump head

Confirm that the correction coefficient is correct, and the system will save the new coefficient by pressing **✓** key. Press **◀** to re-test, press **↶** to return to the system parameter interface without saving the new coefficient.




Figure 44 Calculation Result Interface of Calibration Wizard

If no data is entered, it will display as shown in the figure below, please click **◀** to retest.




Figure 45 No Data Interface of Calibration Wizard

◆ Working Mode

In the main interface and in the stop state, press the MODE key to enter the working mode interface, as shown in the figure below:




Figure 46 Working Mode Interface

• Flow Mode

The pump runs continuously according to the set flow rate and records the accumulated liquid volume.

In the main interface, the flow rate and flow unit can be set, and the flow rate can also be changed by setting the speed. In the preview interface, the model of the current pump head and tube, the current running time, and the accumulated liquid volume are displayed, and the flow rate can be fine-tuned by pressing the increase key and decrease key.




Figure 47 Flow Mode Interface

The functions of delayed start and scheduled stop can be realized in the flow mode. For example, to realize the automatic start with a delay of 30 minutes and the automatic stop after running for 1 hour and 30 minutes after starting, you need to click the time below and set delayed start and run time in the pop-up dialog box.




Figure 48 Timing Time Setting Interface

- Then click the start and stop key , start the delay start process, and there will be an alarm clock symbol in the status bar, as shown in the figure below.





Figure 49 Timing on State Icon

• Time Dispensing Mode

By setting the running time and flow rate, the pump automatically calculates the liquid volume for dispensing.




Figure 50 Time Dispensing Interface


BT/ L Series Peristaltic Pump Operation Manual

Time: Time used for dispensing (hours, minutes or seconds).


Flow Rate: Flow rate during dispensing ($\mu\text{L}/\text{min}$, mL/min or L/min).

Interval Time: Time for intermediate stops in multiple dispensing (hours, minutes or seconds).

Cycle: Number of dispensing. When the number of dispensing is 0, the pump will run cyclically and will not stop until the start/stop key is pressed. When the number of dispensing is 1, the pump will run only once, and the interval time will be invalid. When the number of dispensing is greater than 1, the pump will run to the number of times it is set to run, and it will stop automatically. The preview interface displays the model of the current pump head tube, the current running time, the accumulated liquid volume and the number of times, as shown in the figure below:



Click Mode Setting icon  to choose different group numbers in the interface, and five groups can be pre-stored.



◆ External Control Mode

The speed is controlled by the external input mode analog quantity. the start/stop and direction are controlled by the external signal. Front panel keys do not work.

- When the power is cut off, connect the circuit according to figure 52 or figure 51, and connect the DB15 interface to the back interface of the pump.




Figure 51 Wiring Diagram for Connecting External Power Supply in External Control Mode




Figure 52 Wiring Diagram for Connecting Internal Power Supply in External Control Mode


	Note: Do not connect power to the external control connector. Please provide the correct signals according to the legend pins. Do not exceed the range specified by the signal value. Do not connect the supply voltage across other pins. Otherwise it may cause permanent damage and will not be covered by the warranty.
	Note: Low voltage signals must be isolated from mains power. Use a separate shielded ground input wire.
	Note: Use a qualified protective wire sleeve at the end of the multi-strand cable, otherwise there will be a risk of damage to the equipment.

BT/ L Series Peristaltic Pump Operation Manual

- Turn on the power switch and the screen display the main control interface
- Press the MODE key to choose the flow mode.
- Click Mode Setting icon  to enter the menu, click control mode to choose Voltage Mode or Current Mode.



Current Mode



Voltage Mode

Figure 53 Analog Control Interface

- Click External Start/Stop to choose whether the external control signal to control the pump start/stop is level or pulse.




Figure 54 External Control start/stop Choose Interface

- When the external control start/stop in the mode setting is level mode, connect the switch of external RS_W, open the analog power supply, and the pump will change its speed with the change of analog quantity. Disconnect the switch of external RS_W, and the pump will stop running. When the external control start/stop in the mode setting is pulse mode, connect and then disconnect the switch of external RS_W, open the analog power supply, and the pump will change its speed with the change of analog quantity. Connect and then disconnect the switch of external RS_W again, and the pump will stop running.

- The external control mode can be set in the common parameters. When the direction of external control is in level mode, disconnecting the CW_W switch, the pump operates in clockwise direction, connecting the CW_W switch, the pump operates in counterclockwise direction. When the external control mode is pulse mode, connect and then disconnect the CW_W switch once, and the pump will run clockwise, connect and then disconnect the CW_W switch again, and the pump will run counterclockwise.

◆Communication Mode

RS485 communication supports MODBUS protocol, which can control various functions of the pump. For specific parameter addresses and support instructions, refer to the communication technical standard of Enterprise.

- Turn off the power switch, connect the circuit according to the wiring diagram below, and connect the DB15 interface to the back interface of the pump.




Figure 55 Communication External Power Supply Wiring Diagram




Figure 56 Communication Internal Power Supply Wiring Diagram

	Note: Do not connect power to the external control connector. Please provide the correct signals according to the legend pins. Do not exceed the range specified by the signal value. Do not connect the supply voltage across other pins. Otherwise it may cause permanent damage and will not be covered by the warranty.
	Note: Low voltage signals must be isolated from mains power. Use a separate shielded ground input wire.
	Note: Use a qualified protective wire sleeve at the end of the multi-strand cable, otherwise there will be a risk of damage to the equipment.

- Turn on the power switch and the screen display the main control interface.




Figure 57 Communication Connected Interface

- In internal control mode, the status bar displays the pump number (as #01), which indicates communication connected, otherwise, the communication disconnected.
- Peristaltic pump through the RS485 communication, the default setting for the communication rate of 9600, data bits 8 bits, parity bit even parity, stop bit 1 bit. Communication parameters can be modified in the communication settings of common parameters, as shown in the figure below.




Figure 58 Communication Setting Interface

- After successful connection, the pump functions are controlled by communication commands.

◆ Foot Switch Mode

- Turn off the power switch, connect the circuit according to the wiring diagram below, and connect the DB15 interface to the back interface of the pump.




Figure 59 Foot Switch External Power Supply Wiring Diagram




Figure 60 Foot Switch Internal Power Supply Wiring Diagram

- !** Note: Do not connect power to the external control connector. Please provide the correct signals according to the legend pins. Do not exceed the range specified by the signal value. Do not connect the supply voltage across other pins. Otherwise it may cause permanent damage and will not be covered by the warranty.
- !** Note: Low voltage signals must be isolated from mains power. Use a separate shielded ground input wire.
- !** Note: Use a qualified protective wire sleeve at the end of the multi-strand cable, otherwise there will be a risk of damage to the equipment.

- Turn on the power switch and the screen display the main control interface.
- In internal control mode, volume dispensing mode, time dispensing mode, and program mode. Connect and then disconnect the switch of foot switch, the pump will begin to dispense.
- In foot switch mode, the external control mode is level. Connect the switch of the foot switch, the pump will run. Disconnect it, the pump will stop.
- In the foot switch mode, the external control mode is pulse. Connect and then disconnect the switch of foot switch, the pump will run, and do that again, the pump will stop.




Figure 61 Foot Switch Interface

Malfunction and Maintenance

◆ Warranty and After-sales

● BT/L series peristaltic pump have three-year free warranty

1. The warranty scope only for the whole driver of BT/01L peristaltic pump, pump head, tube and other consumables are not within the scope of this warranty.
2. The warranty period counts from the date of purchase shown on the customer's valid purchase certification.
3. In the warranty period, Enterprise is responsible for the repair and replacement free of charge.
4. This warranty does not cover the damage that caused by human factors such as water, fall, improper use, but Enterprise will repair free, only charge the cost of material fees.

● Special Instructions

Please check the model specifications before using tubes and other consumable products. Please Note that once unpacked and used, returns and exchanges are no longer accepted unless there are quality problems.

◆Drive Spare Parts

Spare parts	Model	Spare part number
Blown fuses	1A	3020200100004
Power cable	250V 10A	3022300200016

◆Daily Maintenance

- Peristaltic pump routine maintenance can refer to the following table.
- There is a cooling fan behind the peristaltic pump, please do not cover it to avoid affecting heat dissipation.
- Peristaltic pumps can not be flushed with water, if the pump tube rupture during operation, the liquid in the pump head should be dried or dried in time.
- Do not use chemical solvents to clean the peristaltic pump and pump head surface.



Note: Always disconnect the pump from the mains power before opening the pump head cover to change tubes, or performing any assembly, disassembly or maintenance activities.

◆Maintenance Worksheet

Regular maintenance of the pump according to the maintenance schedule will help reduce damage to pump components and ensure personal and property safety.

Maintenance Tasks	Frequency	Actions after exception
Check if the pump leaks and damage.	1. Check before starting each time. 2. Daily visual inspection. 3. Periodic inspection during pump operation.	1. Before operating the pump, repair leaks and damage. 2. Replace parts when necessary. 3. Clean up all spilled liquid.
Check for abnormal temperature or noise during pump operation.	1. Daily visual inspection. 2. Periodic inspection during pump operation.	Check and replace worn parts. Please replace the tube in the following situations:
Do you need to replace the tube	1. Check the condition of tube at most every three days	1. When the flow rate is lower than 75% of the original value. 2. When the tube has burst and is badly worn. 3. When the user-defined replacement cycle is reached.
Check pump head and rotor assembly.	1. Regularly check the wheel flexibility every week. 2. Check when replacing tube. 3. Once a year complete inspection for wear and tear, check bearing clearance and function.	1. Worn and damaged surfaces can lead to premature tube failure, replace worn parts in a timely manner.

Table 6 Maintenance Work List

◆ Malfunction Solutions

NO.	Malfunction Type	Malfunction Description	Solutions
1	Hardware	No display	1. Check whether the power cord is connected properly. 2. Check whether the fuse is blown. If it is blown, please contact the manufacturer for replacement.
2	Hardware	Motor does not rotate	1. Check whether the flow or speed is set too small, such as 0.1rpm.
3	Hardware	Motor is trembling	1. Check that the pump head screws and plate rod are tightened.
4	Hardware	The motor rotates in only one direction	1. Check that the direction keys are working normally. 2. Check whether the external control direction signal is normal.
5	Hardware	The key does not work	1. Whether or not it is locked.
6	Hardware	Noisy when the pump is running	1. Around 70 rpm and 120 rpm, it belongs to the resonance frequency of the motor, and it is normal for the sound to be loud. 2. Check that the pump head screws and plate rod are tightened.
7	Hardware/ Software	Communication does not work	First check the software: 1. Whether the mode is communication. 2. Reset the machine address. 3. Check if there are two machines on the bus with the same address. If the problem is not resolved, continue to check the hardware: 4. Check if the connection is correct. 5. Check whether the external control power supply supplies power.
8	Hardware/ Software	External control does not work	First check the software: 1. Whether the mode is external control. If the problem is not resolved, continue to check the hardware: 2. Check if the connection is correct. 3. Check whether the external control power supply supplies power.
9	Hardware/ Software	Inaccurate flow rate display	1. Calibrate the flow rate.

Table 7 Malfunction Solutions Reference Table



Note: This product is not medically certified. When used as a component in a medical device, the medical device itself must have medical certification.



Note: There are no parts in the pump that can be repaired by the user. If the user repairs by himself, the warranty of the pump will be invalid. If there is a fault that cannot be solved after checking the software and connecting the external hardware, please contact the Enterprise, and do not repair by yourself.

Dimensions




Figure 70 Dimensions

Ordering Information

Product Model	Description	Order Number
BT100L		
BT300L		
BT600L		


Table 8 Ordering Information

Optional Accessories Table

Accessories List	Description	Order Number
Foot switch		1060200100017

Table 9 Table of Optional Accessories

Naming Rules



Technical Parameters

BT100L Technical Parameters

Functions

Suitable Pump Heads	YZ15, YZ15X2, YZ25, YZ25X2, DG1, DG2, DG4, DG8, DT10-18, DT10-28, YT15, YT25
Functions	Key control start and stop, direction, full speed, state memory (power-off memory). Foot switch control, external control start and stop, external control direction, with physical isolation, 5V/12V/24V, 5V-24V wide range input, 0-5V/ 0-10V/4-20mA software setting switch. Flow mode, time dispensing mode.
Communication	RS485, MODBUS.
Display	Color LCD touch screen.
Direction Control	Free adjustment of forward and reverse rotation direction.

Performance

Flow Range	0.00011-750mL/min
Speed Range	0.1-150 rpm
Speed Resolution	0.1 rpm, accuracy error less than $\pm 0.2\%$
Adjustment Method	Mask key+ touch screen operation
Display Method	65565 LCD
Applicable Power Supply	AC 100-240V 50Hz/ 60Hz
Wattage	<40W
Working Environment	Temperature 0- 40°C Relative humidity<80%
Dimensions	269×160×183mm
Drive Weight	4.5kg
Degree of Protection	IP31
Degree of Pollution	2

BT300L Technical Parameters

Functions

Suitable Pump Heads	YZ15, YZ15X2, YZ25, YZ25X2, DT15, YT15, YT25
Functions	Key control start and stop, direction, full speed, state memory (power-off memory). Foot switch control, external control start and stop, external control direction, with physical isolation, 5V/12V/24V, 5V-24V wide range input, 0-5V/ 0-10V/4-20mA software setting switch. Flow mode, time dispensing mode.
Communication	RS485, MODBUS.
Display	Color LCD touch screen.
Direction Control	Free adjustment of forward and reverse rotation direction.

Performance

Flow Range	0.005-1750 mL/min
Speed Range	0.1-350 rpm
Speed Resolution	0.1 rpm, accuracy error less than $\pm 0.2\%$
Adjustment Method	Mask key+ touch screen operation
Display Method	65565 LCD
Applicable Power Supply	AC 100-240V 50Hz/ 60Hz
Wattage	<50W
Working Environment	Temperature 0- 40°C Relative humidity<80%
Dimensions	269×160×183mm
Drive Weight	4.5kg
Degree of Protection	IP31
Degree of Pollution	2

BT600L Technical Parameters

Functions

Suitable Pump Heads	Z15, YZ15X2, YZ25, YZ25X2, DT15, YT15, YT25
Functions	Key control start and stop, direction, full speed, state memory (power-off memory). Foot switch control, external control start and stop, external control direction, with physical isolation, 5V/12V/24V, 5V-24V wide range input, 0-5V/ 0-10V/4-20mA software setting switch. Flow mode, time dispensing mode.
Communication	RS485, MODBUS.
Display	Color LCD touch screen.
Direction Control	Free adjustment of forward and reverse rotation direction.

Performance

Flow Range	0.005-3000mL/min
Speed Range	0.1-600 rpm
Speed Resolution	0.1 rpm, accuracy error less than $\pm 0.2\%$
Adjustment Method	Mask key+ touch screen operation
Display Method	65565 LCD
Applicable Power Supply	AC 100-240V 50Hz/ 60Hz
Wattage	<60W
Working Environment	Temperature 0- 40°C Relative humidity<80%
Dimensions	269×160×183mm
Drive Weight	4.5kg
Degree of Protection	IP31
Degree of Pollution	2

◆ Flow Rate Chart of the Pump

Drive Model	Suitable Pump Heads	Channel Number	Suitable tube (mm)	Single-channel Flow Rate(mL/min)
BT100L	DG6-1(6rollers)	1	Wall thickness 0.8 ~ 1, ID≤2.79	0.00016~ 36
	DG10-1(10rollers)	1	Wall thickness 0.8 ~ 1, ID≤2.79	0.00011~ 23
	DG6-2(6rollers)	2	Wall thickness 0.8 ~ 1, ID≤2.79	0.00016~ 36
	DG10-2(10rollers)	2	Wall thickness 0.8 ~ 1, ID≤2.79	0.00011~ 23
	DG6-4(6rollers)	4	Wall thickness 0.8 ~ 1, ID≤2.79	0.00016~ 36
	DG10-4(10rollers)	4	Wall thickness 0.8 ~ 1, ID≤2.79	0.00011~ 23
	DT10-18	1	13#14#, Wall thickness 0.8 ~ 1, ID≤3.17	0.00023~ 64
	DT10-28	2	13#14#, Wall thickness 0.8 ~ 1, ID≤3.17	0.00023~ 64
	DT10-48	4	13#14#, Wall thickness 0.8 ~ 1, ID≤3.17	0.00023~ 64
	YZ15	1	13#14#16#19#25#17#	0.005~ 450
	YZ25	1	15#24#	0.17~ 450
	2×YZ15	2	13#14#16#19#25#17#	0.005~ 450
	2×YZ25	2	15#24#	0.17~ 450
	YT15	1	13#14#16#19#25#17#18#	0.006~ 675
	YT25	1	15#24#35#36#	0.18~ 750
	2×YT15	2	13#14#16#19#25#17#18#	0.006~ 675
	2×YT25	2	15#24#35#36#	0.18~ 750
	DT15-14	1	16#19#25#17#	0.067~ 560
	DT15-24	2	16#19#25#17#	0.067~ 560
	DT15-44	4	16#19#25#	0.067~ 330
BT300L	YZ15	1	13#14#16#19#25#17#	0.005~ 1050
	YZ25	1	15#24#	0.17~ 1050
	2×YZ15	2	13#14#16#19#25#17#	0.005~ 1050
	2×YZ25	2	15#24#	0.17~ 1050
	YT15	1	13#14#16#19#25#17#18#	0.006~ 1575
	YT25	1	15#24#35#36#	0.18~ 1750
	2×YT15	2	13#14#16#19#25#17#18#	0.006~ 1575
	DT15-14	1	16#19#25#17#	0.067~ 1307
	DT15-24	2	16#19#25#17#	0.067~ 1307
	DT15-44	4	16#19#25#	0.067~ 770

BT600L	YZ15	1	13#14#16#19#25#17#	0.005~ 1800
	YZ25	1	15#24#	0.17~ 1800
	2×YZ15	2	13#14#16#19#25#17#	0.005~ 1800
	2×YZ25	2	15#24#	0.17~ 1800
	YT15	1	13#14#16#19#25#17#18#	0.006~ 2700
	YT25	1	15#24#35#36#	0.18~ 3000
	2 x YT15	2	13#14#16#19#25#17#18#	0.006~ 2700

 Note: The above Suitable pump head, the number of suitable channels and the flow rate of a single channel are all obtained from the test of purified water with a Enterprise tube under normal temperature and pressure conditions in the laboratory. This data is for reference only. Due to pressure in actual use , temperature, medium characteristics, tube material and other specific factors, the specific situation needs to consult our engineers.

◆ Suitable Pump Heads for Peristaltic Pump Drives



YZ15/YZ25



YT15/YT25






DG6/DG10



DT10/DT15

◆ External Control Input and Output Performance

Input Switch Value or OC Gate Specification	
Project	Parameter
Input Interface Principle	
Single Signal Input ON Current	$5.5\text{mA} < I_{on} < 15\text{mA}$
Single Signal Input OFF current	$I_{off} < 1.5\text{mA}$
Signal Input Method	switch (closed, open) or NPN transistor OC gate
External Control Input Voltage	5-24V
Isolation Method	Optoelectronic isolation
IOOutput Specification	
Project	Parameter
Principle of Output Interface	
Output Method	NPN transistor OC gate with internal pull-up
Isolation Method	Optoelectronic isolation

Input Analog Specifications		
Project	Parameter	
Interface Principle		
Input Impedance (<100HZ)	0-5V	R1=1KΩ, R2=2.1K
	0 -10V	R1=1KΩ, R2=2.1K
	4-20mA	R1=160Ω, R2=91R
Allowable Error	0-5V、0-10V、 4-20mA	±1%
Resolution	0-5V	5mV
	0-10V	10mV
	4-20mA	16uA
Internal Output Power Specifications		
Project	Parameter	
The Output Voltage	DC12V ± 1V	
Allowable Output Current	< 130mA	
External input Power Specification		
Project	Parameter	
Allowable Input Voltage	DC5-25V	
Allowable Input Current	> 350mA	