



Automatic Label Dispenser




This manual should be made available to all users of this equipment. For best results and for maximum durability of the equipment, carefully read and follow all instructions.

For questions or concerns, e-mail service@ussolid.com, visit www.ussolid.com, or call (800) 243-5428

I. Product Specifications


Brand	U.S. Solid
Model	USS-LD00001
Display	6 digit LED
Applicable Label Width	6 - 140 mm (0.24 to 5.51 inches)
Applicable Label Length	4 - 200 mm (0.16 to 7.87 inches)
Core Diameter	25 - 75 mm (1 to 3 inches)
Max. Roll Diameter	250 mm (9.84 inches)
Power Supply	AC110V, 60Hz

II. Machine Introduction



III. Operating Instructions

1. Mount the Hanger Shaft onto the machine.
2. Install one Core Insert onto the Hanger Shaft, and then install the label roll onto the Core Insert with the labels facing out.
3. Install the white Rubber Washer so that it holds the Core Insert against the roll.
4. Pull the leading edge of the label paper under the Label Guide, through the Press Plate, around the Dispensing Plate and down towards the Rewinder Shaft. Then, grip the label paper end into the groove on the Rewinder Shaft and fix the end with the U Pin. Make sure the paper is fairly straight. (See the attached picture.)
5. Gently adjust the position of the black rubber on the Label Guide rod. Note that it is important to exercise care on this step; too much force may cause the label to tear.



6. Point the sensor towards the desired label stop position. You can either pivot the sensor on the shaft, or rotate the metal bracket, or both.

For questions or concerns, e-mail service@ussolid.com, visit www.ussolid.com, or call (800) 243-5428

7. Turn the Power Switch to “On”.
8. Adjust the Speed and Length Knobs until the desired settings of the label feed are achieved.

IV. Applications

This machine is suitable for self-adhesive labels, barcode labels, security labels, packaging labels, anti-counterfeit labels, hot stamping stickers, stickers, printing patterns, chrome paper, and many more!

V. Pack List

- 1 – Automatic Label Dispenser
- 1 – Power Cable
- 1 – User Manual

VI. Warranty

The machine’s motor and circuit board have a 1 year warranty. This warranty covers any defects in material or workmanship under normal use.

Within 30 days of delivery, U.S. Solid will either work with you to repair your product with replacement parts, replace the product after receiving the returned defective machine, or accept a returned defective machine for a full refund.

After the first 30 days but still within the first 1 year of delivery, U.S. Solid will send new or refurbished replacement parts at no charge so you can repair the product on your own.